

SUPPLEMENTARY MACHINE SERVICE BULLETIN #40-E

SUBJECT: FULL AUTOMATIC PARTS & PRICE LIST


DATE: AUGUST 16, 1928

TO ALL OFFICES:

Effective September 1, 1928, Field Offices will be billed for all repair parts for Full Automatic and 3-Series machines on the regular basis of list less 35% and charges are to be made wherever possible to customers whose machines of these models require repair service after the guarantee has expired.

We are attaching a complete parts and assembly list together with the prices covering this material. This will act as a supplement to Machine Service Bulletins #40 and #48 and will supersede pages one to nine inclusive of Bulletin #40 and the parts and assembly list attached to Bulletin #48. Therefore, these obsolete sheets should be destroyed.

It will be noted that the Plate and Group numbers are shown on the new parts and price list. This is to facilitate the locating of illustrations of the various parts and assemblies, for identification and reference purposes.



General Service Manager

FMS:C
Encl.

SUPPLEMENT E

KEYBOARD SECTION, ASSEMBLIES
(Plate 36, Group 50)

Assembly No.	Name	Quantity Per Machine		Price
		16	20	
1-0100 $\frac{1}{2}$ -AA	Keyboard. Complete (For "1-AA" Model)		1	\$55.00
1-100 $\frac{1}{2}$ -AA	Keyboard. Complete (For "2-AA" ")		1	60.00
12-010 $\frac{1}{2}$	Top Keyboard Plate & Connections (For "1-AA" Model)		1	3.00
12-10 $\frac{1}{2}$	Top Keyboard Plate & Connections (For "2-AA" Model)		1	3.00
12-2 $\frac{1}{2}$	Rear Keyboard Cross Frame & Pins		1	3.25
12-3 $\frac{1}{2}$	Front Keyboard Cross Frame, Pins & Connections		1	3.75
12-20 $\frac{1}{2}$	Bottom Keyboard Plate & Connections		1	2.00
12-50	Connecting Bar & Cam Shift Lever for Division Lever	1	1	.75

KEYBOARD SECTION, PARTS
(Plate 36, Group 50)

Part No.				
1200 $\frac{1}{2}$	Front Keyboard Cross Frame		1	1.35
1201 $\frac{1}{2}$	Rear Keyboard Cross Frame		1	1.20
1205	Connecting Bar for Cam Shifter & Division Lever	1	1	.30
1209	Cam Shift Lever on Connecting Bar	1	1	.25
1212 $\frac{1}{2}$	Bottom Keyboard Plate		1	2.00
1213 $\frac{1}{2}$	Top Keyboard Plate (For "1-AA" Model)		1	2.60
1214 $\frac{1}{2}$	Top Keyboard Plate (For "2-AA" ")		1	3.00
1215 $\frac{1}{2}$	Keyboard Clearing & Lock Bar		1	.25
1228	Hinge for Cam Shifter	1	1	.30
1229	Right Hand Bracket for Zero Key Mechanism	1	1	.05
1230	Left Hand Bracket for Zero Key Mechanism	1	1	.05
1252	Collar Nut to Hold Connecting Bar	2	2	.05
1267	Pivot Stud for Cam Shifting Levers	4	4	.05
1273	Spring Stud in Front Keyboard Frame & Cam	1	1	.05
1276	Pin on Keyboard Cross Frames	16	20	.05
1288	Rivet for Cam Shifter Hinge	2	2	.05
1331	Bracket for Front Cover Plate	1	1	.30
1360	Screw to Hold Keyboard Cross Frame	4	4	.05
1362	Screw to Hold Keyboard Bottom Plate	18	18	.05
1363	Screw to Hold Keyboard Top Plate & connecting Bar for Cam Shifter & Division Lever	13	13	.05

INTERMEDIATE GEAR SHAFT SECTION, ASSEMBLIES
(Plate 37, Group 51)

Assembly No.				
2-100 $\frac{1}{2}$ -AA	Selecting Shaft Complete		1	20.00
12-4-#10	Four Teeth Selecting Gear		1	.80

INTERMEDIATE GEAR SHAFT SECTION, ASSEMBLIES (Cont'd.)
(Plate 37, Group 51)

Page 2

Assembly No.	Name	Quantity Per Machine		Price
		16	20	
12-5-#10	Five Teeth Selecting Gear		1	.70
12-32	Crank Arm & Stud	1	1	.75

INTERMEDIATE GEAR SHAFT SECTION, PARTS
(Plate 37, Group 51)

Part No.				
1258	Crank Arm	1	1	.50
1263	Five Teeth Selecting Gear	1	1	.60
1264	Four Teeth Selecting Gear	1	1	.55
1299	Knock Off Pin for Crank Arm	1	1	.05

CARRIAGE SECTION, ASSEMBLIES
(Plate 37, Group 52)

Assembly No.				
5-014 $\frac{1}{2}$ -AA	Carriage Case & Riveted Parts (For "1" series)		1	\$25.00
5-14 $\frac{1}{2}$ -AA	Carriage Case & Riveted Parts (For "2" series)		1	25.00
5-0100 $\frac{1}{2}$ -AA	Carriage Complete (For "1" series)		1	95.00
5-100 $\frac{1}{2}$ -AA	Carriage Complete (For "2" series)		1	100.00
12-33 $\frac{1}{2}$	Left Hand Carriage Locking Ledge with Extension		1	.40

CARRIAGE SECTION, PARTS
(Plate 37, Group 52)

Part No.				
1223 $\frac{1}{2}$	Left Hand Carriage Locking Ledge		1	.40
1280	Stud on Left Hand Carriage Locking Ledge	1	1	.05
1324	Multiplier Extension on Left Hand Carriage Locking Ledge	1	1	.15
1450	Screw for Multiplier Extension	1	1	.05

SIDE FRAMES AND CONNECTIONS SECTION,
ASSEMBLIES

Assembly No.	Pl. No.	Gr. No.	Name		
6-10-AA	37	53	Left Hand Side Frame & Riveted Parts	1	10.00
11-61 $\frac{1}{2}$	38	54	Bottom Pan	1	4.75
11-67 $\frac{1}{2}$	38	54	Cover Case, Front Plate	1	15.00
11-65	38	54	Cover Case, Left Hand Side Plate	1	14.50

SIDE FRAMES AND CONNECTIONS SECTION, PARTS

Part No.					
1151	38	55	Bracket for Cam Actuating Arm	1	1.15
1177	38	54	Linoleum Lining for Rear of Left Hand Cover Case	1	.20
1178	38	54	Linoleum Lining for Front of Left Hand Cover Case	1	.25

INTERMEDIATE GEAR SHAFT SECTION, ASSEMBLIES (Cont'd.) Page 3
(Plate 37, Group 51)

Part No.	Pl.	Gr.	Name	Quantity Per Machine		Price
1179½	38	54	Right Top Linoleum Strip for Front Cover Plate	1	1	.10
1180	38	54	Left Top Linoleum Strip for Front Cover Plate	1	1	.05
1181½	38	54	Bottom Linoleum Strip for Front Cover Plate	1	1	.30
1234	38	55	Check Pawl for Extra Carry Gear	1	1	.20
1256	38	55	Check Nut (#6-40 thd's)	4	4	.05
1269	37	53	Pivot Stud for Double Arm Lever	1	1	.05
1271	37	53	Spring Pin for Trip Lever Spring	1	1	.05
1272	37	53	Spring Pin for Division Lever Spring	1	1	.05
1286	38	55	Screw for Extra Carry Gear Check Pawl	1	1	.05
1289	38	55	Screw to Hold Bracket for Cam Actuating Arm	5	5	.05
1290	37	53	Spring Pin for Double Arm Lever Spring	1	1	.05
1291	37	53	Screw for 733-1/8	1	1	.05
1294	38	55	Pivot Screw for Clutch Yoke	1	1	.65
1297	38	55	Stop Screw for Cam Actuating Arm	3	3	.05
1298	37-39, 53-56		Pivot Stud for Machine Locator Arm Locking Latch	1	1	.05
1329	38	54	Linoleum Retaining Strip for Front of Left Side Cover Case	2	2	.35
1330	38	54	Linoleum Retaining Strip for Rear of Left Side Cover Case	1	1	.70
1331	36	50	Bracket for Front Cover Plate	1	1	.25
1333½	38	54	Linoleum Retaining Strip for Right Top on Front Cover Plate	1	1	.10
1334	38	54	Linoleum Retaining Strip for Left Top on Front Cover Plate	1	1	.10
1335½	38	54	Linoleum Retaining Strip for Bottom on Front Cover Plate	1	1	.20
1355	39	56	Locating Pin for Release Lever	1	1	.05
1360	36	50	Screw to Hold Keyboard Cross Frame	4	4	.05
1375	38	55	Frame Support	2	2	.95
1398	39	56	Holding Screw for Left Side Cover Plate	2	2	.05

AUTOMATIC STOP, DIVISION AND CARRIAGE SHIFT
SECTION, ASSEMBLIES

Assembly No.						
11-81	42	60	Carriage Shifter Complete	1	1	2.25
12-41	41	58	Division Lever Handle & Stud	1	1	.55
12-42	41	58	Division Lever & Actuating Pawl	1	1	1.75
12-44	39	56	Locking Latch & Release Lever for Machine Locator Locking Arm	1	1	.70

SECTION, ASSEMBLIES

Assembly No.	Pl. No.	Gr. No.	Name	Quantity Per Machine		Price
12-50	36	50	Connecting Bar & Cam Shift Lever for Division Lever	1	1	.75
12-51	41	59	Coupling Lever for Carriage Shift Mechanism	1	1	.35
12-52	41	59	Double Arm Lever for Carriage Shift Mechanism	1	1	.90
12-54	41	59	Cam Actuating Lever for Carriage Shift Mechanism	1	1	.40
12-56	41	59	Carriage Shift Cam & Ratchet	2	2	1.00
12-57	42	60	Cam Shifter for Carriage Shift Cams	1	1	.80
12-60	39	56	Machine Locator Arm	1	1	1.10
12-70 $\frac{1}{2}$	39	56	Rock Lever & Connecting Link for Crank Arm		1	.95
12-72	39	56	Cycle Stopping Arm, Latch, etc.	1	1	1.60
12-74	40	57	Machine Sopping Lever, Lifter, etc.	1	1	.65
12-77	40	57	Over Carry Trip Lever	1	1	.50
12-78	40	57	Extension for Over Carry Trip Lever	1	1	.25
12-81	40	57	Clutch Yoke Complete	1	1	2.60
12-82	41	58	Blank with Spring Stud for Extra Carry Gear Check Pawl Spring	1	1	.20

AUTOMATIC STOP, DIVISION AND CARRIAGE SHIFT
SECTION, PARTS

Part No.						
1000	41	58	Spring for Division Lever Check Pawl	1	1	.05
1001	41	59	Spring for Cam Actuating Arm	1	1	.10
1002	41	59	Spring for Double Arm Lever	1	1	.05
1003	42	60	Spring for Cam Shifter	1	1	.05
1004	40	57	Spring for Over Carry Trip Lever	1	1	.05
1005	41	59	Spring for Cams	2	2	.05
1006	40-41, 57-58		Spring for Division Lever Actuating Pawl Machine Locator Locking Latch	1	1	.05
1013	43-44-46-50, 62-63-66		Spring for Release Bar	1	1	.05
1018	42	61	Spring on Cam Locking Latch	1	1	.05
1100	42	60	Carriage Shift Rod	1	1	.15
1153	39	56	Motor Bracket	1	1	6.75
1175	42	60	Carriage Shift Knob	1	1	.50
1176	42	60	Rubber Ring for Carriage Shaft Knob	1	1	.05
1202	42	60	Cam Shifter	1	1	.40
1203	41	59	Coupling Lever	1	1	.65
1204	41	58	Division Lever	1	1	2.25
1205	36	50	Connecting Bar for Cam Shifter & Division Lever	1	1	.30
1206	42	61	Release Bar Actuating Lever	1	1	.20
1207	42	61	Bracket for Release Bar Actuating Lever	1	1	.25

SECTION, PARTS (Cont'd)

Part No.	Pl. No.	Gr. No.	Name	Quantity		Price
				Per Machine	16 20	
1208	39	56	Release Lever for Machine Locator			
			Locking Latch	1	1	.30
1209	36	50	Cam Shift Lever on Connecting Bar	1	1	.25
1210	42	60	Outside Fork for Cam Shifter	1	1	.25
1211	40	57	Lifter for Division Lever Return			
			Push Arm	1	1	.20
1216	39	56	Flexible Tip for Machine Locator			
			Arm	1	1	.25
1217	41	59	Double Arm Lever	1	1	.70
1218	41	59	Cam Actuating Lever	1	1	.25
1219	41	58	Latch for Division Lever	1	1	.50
1220	41	58	Actuating Pawl for Division Lever	1	1	.25
1221	39	56	Connecting Link for Crank Arm &			
			Rock Lever	1	1	.05
1222	39	56	Latch for Machine Locator Arm	1	1	.40
1224	39	56	Cycle Stopping Arm	1	1	.60
1225	40	57	Locking Latch Behind Clutch Yoke	1	1	.25
1227	39	56	Locking Latch for Machine Locator			
			Latch	1	1	.25
1228	36	50	Hinge for Cam Shifter	1	1	.30
1231	40	57	Flexible End for Over Carry Trip			
			Lever	1	1	.15
1232	40	57	Division Lever Return Push Arm	1	1	.20
1233	40	57	Extension Arm for Clutch Yoke	1	1	.35
1235	42	61	Release Bar for Cam Locking Latch	1	1	.35
1236	41	58	Division Lever Handle	1	1	.25
1237	40	57	Clutch Yoke	1	1	1.10
1241	41	59	Carriage Shift Cam	2	2	.20
1243	41	58	Guide for Division Lever	1	1	.25
1250	39	56	Hub for Machine Locator Arm			
			Locking Latch	1	1	.05
1251	41	58	Hub for Division Lever	1	1	.05
1252	36	50	Collar Nut to Hold Connecting Bar	2	2	.05
1253	40	57	Hub for Extra Carry Over Trip			
			Lever	1	1	.05
1254	40	57	Collar for Carry Over Trip Lever	1	1	.05
1255	40	57	Hub for Clutch Yoke	1	1	.05
1256	38	55	Check Nut (6-40 thd's)	4	4	.05
1257	41	59	Hub for Double Arm Lever	1	1	.10
1258	37	51	Crank Arm	1	1	.50
1259	41	59	Cam Roller	1	1	.05
1260	41	59	Roller for Double Arm Lever	1	1	.05
1261	40	57	Pivot Collar for Extra Carry			
			Over Trip Lever	1	1	.15
1262	41	59	Hub for Coupling Lever	1	1	.05
1265	40	57	Pin for Clutch Yoke	1	1	.05
1266	39	56	Pivot Stud for Machine Locator			
			Locking Latch	2	2	.05
1267	42	61	Pivot Stud for Cam Shifting Levers	4	4	.05
1268	40	57	Stud for Extension Arm	1	1	.05
1270	40	57	Pivot Stud for Machine Locator			
			Arm Lifter	1	1	.05

SECTION, PARTS (Cont'd)

Assembly No.	Pl. No.	Gr. No.	Name	Quantity Per Machine		Price
				16	20	
1273	41	59	Spring Stud in Keyboard Frame & Cam	1	1	.05
1274	39	56	Restoring Stud for Clutch Yoke	1	1	.05
1275	41	58	Connecting Pin on Division Lever Handle	1	1	.05
1277	41	58	Connecting Pin for Division Lever & Handle	1	1	.05
1278	42	60	Hinge Pin for Cam Shifter	1	1	.05
1279	42	60	Cam Shifter Rivet	2	2	.05
1281	41	59	Spacing Rod	1	1	.05
1282	39	56	Pivot Stud for Coupling Lever	1	1	.20
1283	41	58	Pivot Stud for Actuating Pawl of Division Lever	1	1	.10
1284	39	56	Extension Stud on Bumper	1	1	.05
1285	39	56	Stop Stud for Cycle Stopping Latch	1	1	.05
1287	42	61	Screw to Hold Release Bar for Cam Locking Latch	2	2	.05
1288	36	50	Rivet for Cam Shifter Hinge	2	2	.05
1291	37	53	Screw for 733-1/8	1	1	.05
1292	41	59	Pivot Stud for Cam Actuating Arm	1	1	.05
1293	41	59	Cam Roller Stud	1	1	.05
1294	38	55	Pivot Screw for Clutch Yoke	1	1	.65
1295	41	58	Knock Off Stud for Clutch Yoke Latch on Division Lever	1	1	.05
1296	41	59	Stud for Roller on Double Arm Roller	1	1	.05
1297	38	55	Stop Screw for Cam Actuating Arm	3	3	.05
1298	39	56	Pivot Stud for Machine Locator Arm Locking Latch	1	1	.05
1299	37	51	Knock Off Pin for Crank Arm	1	1	.05
1307	41	59	Washer Between Carriage Shift Cams	1	1	.05
1317	42	61	Cam Locking Latch	1	1	.40
1326	42	60	Retaining Strip for Cam Shifter Hinge Pin	1	1	.20
1350	41	58	Pin for Division Lever Handle	1	1	.05
1351	39	56	Coupling Pin for Connecting Link	1	1	.05
1352	41	58	Pivot Screw for Division Lever Latch	1	1	.10
1353	40	57	Stop Stud Screw for Coupling Lever	1	1	.20
1354	41	58	Pivot Screw for Division Lever	1	1	.10
1355	39	56	Locating Pin for Release Lever	1	1	.05
1358	42	60	Ratchet for Carriage Shift Shaft	2	2	.30
1361	41	59	Ratchet for Carriage Shift Cams	2	2	.40
1368	42	61	Screw for Cam Locking Latch	1	1	.05
1375	38	55	Frame Support	2	2	.95
1397	42	60	Screw for Carriage Shift Knob	2	2	.05
1398	39	56	Holding Screw for Left Side Cover Plate	2	2	.05

NOTE: The following assembly and parts belong to the Multiplier Section, but are to be found on the inside of the 1150 side frame.

Page 7

ASSEMBLIES

Assembly No.	Pl. No.	Gr. No.	Name	Quantity Per Machine All Models	Price
13-25	42	61	Release Bar Actuating Lever with Bracket	1	.50

PARTS

Part No.					
1018	42	61	Spring on Cam Locking Latch	1	.05
1206	42	61	Release Bar Actuating Lever	1	.20
1207	42	61	Bracket for Release Bar Actuating Lever	1	.25
1235	42	61	Release Bar for Cam Locking Latch	1	.35
1267	42	61	Pivot Stud	1	.05
1287	42	61	Screw to Hold Release Bar for Cam Locking Latch	2	.05
1317	42	61	Cam Locking Latch	1	.40
1368	42	61	Screw for Cam Locking Latch	1	.05

ASSEMBLY MULTIPLIER SECTION, ASSEMBLIES

Assembly No.					
13-0	42	62	Right Hand Side Frame & Riveted Parts	1	8.00
13-2	42	62	Locking Latch & Release Hook for Starting Lever	1	.40
13-4	43	62	Rack Shifting Cam with Hub	1	3.00
13-5	43	62	Knock Off Lever & Release Arm for Key Locking Bail	1	.70
13-7	43	62	Zero Key Trip Actuating Lever with Pawl	1	.75
13-9	43	62	Trip Lifter with Hub	1	.65
13-10	43	62	Left Hand Side Frame & Riveted Parts	1	1.80
13-14	43-45	62	Back Stop with Pawl for Multiplier Selector Rack	1	.90
13-15	45	64	Rack Shifter with Pawl & Roller	1	.90
13-18	45	64	Locking Latch for Key Locking Bail, with Brace & Pin	1	1.30
13-20	46	65	Keyboard Bottom Plate & Riveted Parts	1	.40
13-22	45	64	Multiplier Back Frame & Riveted Parts	1	.90
13-23	45	64	Multiplier Front Frame & Riveted Parts	1	1.20
13-30	45	64	Shutter Box & Riveted Parts	1	6.00
13-32	45	64	Downward Locking Bail for Key Stems with Pin	1	1.15
13-34	46	65	Multiplier Key ("0" to "9") with Stop Pawl	10	.25

MULTIPLIER SECTION, PARTS

Part No.					
51-A	43-45, 62-64		Washer	1	.05
58	40	57	Washer under Frame Screws	3	.05
85	44	63	Retaining Ring for 1/8 Stud	6	.05
105	46	65	Key Stem Washer	20	.05
127	46	65	Inserted Stop for Key Stems	10	.05
162	45-46, 64-66		Spring Stud	5	.05

MULTIPLIER SECTION, PARTS
(Cont'd)

Page 8

Part No.	Pl. No.	Gr. No.	Name	Quantity Per Machine (All Models)	Price
180	46	65	Key Stem Spring	10	1.80 .08
181	46	65	Spring	2	.05
190	46	65	White Key Button (For Even Numbers)	4	.10
190 $\frac{1}{2}$			White Key Button (For Odd Numbers)	5	.10
192-D	46	65	Zero Key Button	1	.10
194	46	65	Felt Key Washer	10	.03
248-B	45	64	Washer	2	.05
657	43	62	Pivot Stud	1	.05
785	46	65	Spring	3	.10
880	46-51	65	Spring	10	.05
1007	43-44, 62-63		Spring for Starting Lever	1	.05
1008	43-44, 62-63		Spring for Starting Lever Locking Latch O Key Lever	2	.05
1009	43-44, 62-63		Spring for Release Hook on Starting Lever Locking Latch	1	.05
1010	45	64	Spring for Rack Shifter	1	.05
1011	45	64	Spring for Back Stop Pawl	1	.05
1012	45	64	Spring for Selector Rack	1	.05
1014	45	64	Spring for Release Lifter	1	.05
1015	43-44, 62-63		Spring on Trip Lifter	1	.05
1016	43-44, 62-63		Spring on Knock Off Lever for Locking Bail Latch	1	.05
1017	46	65	Spring on Lever for O Key Locking Slide	1	.05
1238	45	64	Multiplier Back Frame	1	.80
1239	45	64	Multiplier Front Frame	1	.80
1240	46	65	Stop Pawl for Multiplier Key Stem	10	.05
1242	44	63	Release Hook for Starting Lever Locking Latch	1	.15
1244	44-46, 63-66		Starting Lever	1	.40
1245	45	64	Multiplier Selector Rack	1	.70
1246	46	65	Multiplier Key "0" to "9"	10	.25
1247	45	64	Downward Locking Bail for Key Stems	1	1.05
1248	46	65	Multiplier Top Plate	1	.95
1249	44	63	Starting Lever Locking Latch	1	.20
1266	44	63	Pivot Stud	2	.05
1267	42-44-46, 61-63-66		Pivot Stud	15	.05
1300	44	63	Rack Shifting Cam	1	.45
1301	46	66	Right Side Multiplier Frame	1	2.85
1302	43	62	Left Side Multiplier Frame	1	1.50
1303	45	64	Back Stop for Multiplier Selector Rack	1	.50
1304	44	63	Zero Key Trip Actuating Lever	1	.40
1305	46	65	Lever for Zero Key Locking Slide	1	.25
1306	44	63	Pawl for Zero Key Trip Actuating Lever	1	.20
1308	43-44, 62-63		Trip Lifter Latch	1	.25
1309	46	65	Zero Key Locking Slide	1	.25
1310	45	64	Locking Latch for Key Locking Bail	1	.55
1311	43	62	Release Bar	1	.30
1312	44	63	Knock Off Lever for Release Arm of Key Locking Bail	1	.35

MULTIPLIER SECTION, PARTS
(Cont'd)

Page 9

Part No.	Pl. No.	Gr. No.	Name	Quantity Per Machine (All Models)	Price
1313	44	63	Release Arm of Locking Bail	1	.25
1314	46	65	Multiplier Bottom Plate	1	.35
1315	45	64	Shutter Box for Multiplier Selector Rack	1	1.80
1316	45	64	Upward Locking Bail for Key Stems	1	1.00
1318	45	64	Rack Shifter	1	.75
1319	45	64	Release Lifter	2	.45
1320	45	64	Cam Shift Lever on Front Frame	1	.15
1321	44	63	Trip Lifter	1	.25
1322	45	64	Rack Shifter Pawl	2	.30
1323	43-44,	62-63	Intermediate Trip Lifter	1	.35
1362	43	62	Screw to Hold Keyboard Bottom Plate	18	.05
1363	43-46,	62-65	Screw to Hold Keyboard Top Plate	7	.05
1364	45	64	Roller for Rack Shifter	1	.05
1365	45	64	Stud for Roller on Rack Shifter	1	.05
1366	44	63	Hub for Rack Shifting Cam	1	.05
1367	44	63	Pivot Stud for Rack Shifting Cam	1	.05
1369	45	64	Stud for Multiplier Selector Rack	1	.05
1370	45	64	Stud for Front & Back Frame	2	.05
1371	43	62	Stud for Left Side Frame to Hold Case	2	.15
1372	45	64	Brace for Locking Latch of Key Locking Bail	1	.40
1373	45	64	Spring Stud for Multiplier Selector Rack	1	.05
1374	45	64	Pivot Rod for Rack Shifter & Bail Locking Latch	2	.05
1376	45	64	Rivet for Release Lifter	6	.05
1377	45	64	Pin for Locking Latch of Key Locking Bail	1	.05
1378	44	63	Hub for Trip Lifter	1	.05
1379	43	62	Brace Rod for Multiplier Frame	1	.05
1380	43	62	Collar for Intermediate Trip Lifter Stud	1	.05
1381	45	64	Stud for Upward Key Stem Locking Bail	2	.05
1382	46	66	Stud for Trip Lifter	1	.05
1383	45	64	Stud for Rack Shifter Pawl	2	.05
1384	44	63	Stud for Intermediate Trip Lifter	1	.05
1385	44	63	Guide Screw for Bail Knock Off Lever	2	.05
1386	45	64	Pin on Locking Bail for Key Stem	1	.05
1387	46	66	Spring Stud for Right Side Frame	1	.05
1388	46	65	Collar Nut for O Key Locking Slide Lever	1	.05
1389	45	64	Check Nut #4-48 (on 1390)	1	.05
1390	45	64	Stop Screw for Upward Locking Bail	1	.05
1391	46	65	Spring Stud on Multiplier Bottom Plate	1	.05
1392	45	64	Stud to Hold Cam Shift Lever on Front Frame	1	.05
1393	45	64	Collar Under Cam Shift Lever on Front Frame	1	.05
1394	43-44,	62-63	Shoulder Screw for Release Arm for Locking Bail	2	.05
1395	43-44,	62-63	Shoulder Screw for O Key Trip Actuating Lever	1	.05
1396	43	62	Screw to Hold Multiplier Frame	3	.05

The parts listed in the following are not illustrated by plate and group numbers in Machine Service Bulletin #40, but are included in this list for reference purposes.

Assembly No.	Name	Quantity All Models	Price
1-0100AA	Keyboard Complete - 1 series	1	\$50.00
1-100AA	" " 2AA & 2AS Models	1	55.00
2-100AA	Selecting Gear Shaft Complete	1	18.00
5-014AA	Carriage Case Complete - 1 series	1	22.50
5-14AA	" " " 2 "	1	22.50
5-0100AA	Carriage Complete - 1 series	1	85.00
5-100AA	" " 2 "	1	90.00
6-66	R.H. Cover Plate Complete	1	5.75
6-68	Rear " " " 0 series	1	5.50
6-68 $\frac{1}{2}$ D	" " " " 1,2,3 "	1	6.00
11-67	Front Cover Case Complete-16 Pl.	1	14.50
11-67 $\frac{1}{2}$	" " " " 20 "	1	15.00
12-2	Rear Keyboard Frame Assembly	1	3.00
12-3	Front " " "	1	3.00
12-10	Top K.B. Plate & Connections 2 Series	1	2.75
12-010	Top K.B. Plate & Connections 1 series	1	2.75
12-20	Bottom K.B. Plate & Connections	1	1.90
12-33	L. H. Carriage Locking Ledge with Stud	1	.35
12-70	Rock Lever & Connecting Link for Crank	1	1.00
13-100	Multiplier Section Complete	1	47.50
Part No.			
1179	Upper R. H. Linoleum for Front Cover Case	1	.10
1181	Lower " " " " "	1	.20
1200	Front Keyboard Cross Frame	1	1.15
1201	Rear " " " "	1	1.00
1212	Keyboard Bottom Plate	1	1.75
1213	Keyboard Top Plate - 1 series	1	1.75
1214	" " " - 2 "	1	2.75
1215	Keyboard Lock Bar	1	.20
1233	Extension Arm for Clutch Yoke	1	.30
1333	Upper R. H. Clamping Strip for Front Plate	1	.10
1335	Lower " " " " "	1	.15

Mr. G. W. Sisler
Toledo, Ohio